

# 05 Objects

- Manage
- Actions
- Viewers

---

This chapter provides information about objects and a description of how to configure objects.

## Button/Switch

Different button has different function. Such as: Bit Switch; Bit lamp; Word Switch; Word lamp; Function Switch; Keypad Switch; Combination Switch.

### Bit switch

Bit switch is designed to access the bit-address of the PLC/HMI. When bit switch is triggered, the changing of "Write Address" depends on the mode setting. When "Read" option is selected, the "Read Address" is editable.

### General

To operate, monitor and display the specified PLC or HMI bit address. When the bit switch is pressed, the bit value of the operation address changes as described by the switch type. When Monitor is available, the state displayed by the bit switch is the state of the bit to which the monitor address is pointing.

Bit switch

General Text Graphic Security Animation

Read-write

Write Address HDX2.0 Edit

Read  Same read-write address

Read Address HDX2.0 Edit

Mode

Set OFF  Set ON  Momentary  Switch

Display

Inverted Display  Quick Read

Blink

Frequency 10 100ms

Control Bit Blink when ON Blink when ON Blink when OFF Edit

Min.Hold Time 0 ms

Indirect Addressing

Read Address Edit

Write Address Edit

确定 取消 帮助

## Read-write

- **Write Address:** Bit switch controls PLC or HMI address.
- **Read Address:** Read and display PLC or HMI bit address state.

## Mode

- **Set OFF:** set off the write address.
- **Set ON:** set on the write address.
- **Momentary:** set on the write address when switch is pressed, and set off when switch is released.
- **Delay:** set off the write address after a delay. (for example: assign the delay time as 5, write address will be set off after released 5 ms.)
- **Switch:** switch between 0 and 1 each time the switch is triggered.

## Display

- **Inverted Display:** Display the state picture and text of the object reversely.
- **Quick Read:** The speed of configuring the object is priority to other objects.

**Blink:** Control the state of blink by the bit address of control bit. Blinking while control bit is triggered, the frequency is editable;

- **Blink when ON:** blink when control bit is ON.
- **Blink when OFF:** blink when control bit is OFF.

**Minimum hold time:** Only when the time of pressing the object is greater than or equal to the set minimum hold time will the function of the object be performed.

### Indirect addressing:

- **Read address:** Use the value of the read address to determine the address A after deviation, and use the address A as the read address of the object.

**For example::** HDX11.0 is the read address of the object. The three indirect read address is D0, E1 and HDW2. The system would read the value of address HDW2.


If its value is 22, and the second indirect read address E1 would update to E23, then the system would read the value of E23.

If its value is 33, then the first indirect read address D0 would update to D33, then the value of D33 is 44, that is, the bit of deviation is 44 bits.


A word has 16 bits, divide 16 into 44, and the answer is 2, remainder 12. Therefore, the read address of object is update from HDX11.0 to HDX13.12, and the final read address is HDX13.12.

**Write address:** It is the same as the read address.

## Text



**All languages:** Edit the texts of all the languages of the object in a time. A maximum of 8 languages supported.



**All states:** Edit the texts of all the states of the object in a time.


**Font:** Set the font of the text after selecting the state. The number of the characters input is displayed.

**Copy attribute to states:** Set the color of font after selecting state and text, and click "Copy attribute to states", then they would be in the same color.

**Copy text:** Click it and the texts of all the objects would be the same.

**Copy style:** Click it and the styles of all the objects would be the same.


## Graphic



**Bitmap:** You could design beautiful scenes with bitmap. Static diagram and bitmap with states are supported.

**Vectogram:** Use to figure SVG vector diagram is concise and lively geometry, generally shows the various industrial field, with the performance of the more abundant than bitmap method, and the vector diagram drawing will not be needed or scaling distortion.

## Security




## Object lock

- **Lock address:** Using interlock address, address 0 means that the object would be locked and display a lock icon. Only when the interlock - bit address points to 1 will the bit switch be operated.
- **Hide "lock" icon:** If don't want to display the icon, you may check it. will be "no show" lock "icon" tick.
- **Lock when "ON":** check it and the bit address will be locked when the interlock address is set to 1.

**Touch available:** If you check it, you could operate the object when you touch it.

**Enable beep:** If you check it, the object will beep when you touch it.

**Extended trigger functions.** It is only valid for PLC address.




### Access denied setting

Users can set enable password for object. There are following operating setting when user permissions are insufficient. But "Pop login screen" and "Hide object" are mutually exclusive.

- **Pop login screen**
  - Every time: Userlogin screen will pop-up when user permissions are insufficient;
  - When change user: Userlogin screen will pop-up when user permissions, and if users logged in successfully, the previous users will log out.
  - Pop once: userlogin screen will pop-up when user permissions are insufficient, but when user enter the right password, this object can be operated by anyone.
- **Hide object:** When the user has no permission, the object is hided. When the user has the permission, the object is displayed and can be operated.

### Animation





### Data format

This format is for settings address, and it is fixed for all objects.

### Proportion:

The proportional gain setting is a proportional change to the moving and scaling values.  $\text{Result} = \text{Gain} * \text{original value} + \text{Offset}$ . This function is just for display. Actual value is still the original value.

For example, the HDW1 original value is 5, Gain is 0.001, Offset is 0. The final result will be displayed as 0.005, while HDW1 actual value still is 5.

For example: If the proportional gain value is  $x$  and the moving or scaling value is  $y$ , then the actual moving or scaling value is  $(x*y)$ .

### (Movement

The function of [Movement] is to move the position of object on the screen according to the value of address and movement type.

There are three movement type:

- X-axis movement.
- Y-axis movement.
- XY-axis movement.

### **For example**

If the starting address of the movement is HDW10 and the movement type is [XY axis movement], HDW10 controls the X-axis movement, and HDW11 controls the Y-axis movement.

### **Deform**

Deform object display size on screen, mainly depends on width and height.

Deform type: left, right, up, down, left and right, up and down, right/left and up/down, right/left or up/down.

## **Address editor**

The address editor is a tool used to assist in generating address strings. The address of object is composed of connection, device station number, device type and address number.

**Edit**
✕

Word address0: [HDW1] ▾

Connection: HMI Local Address ▾

Address Type: HDW ▾

Data Format: Word ▾

Byte order: Normal ▾

Address No.:

Extended tag1:

Extended tag2:

Note: Word Address.  
Mark: HDW.  
No.: 0~299999.  
Decimal

A B C D E F

7 8 9 ←

4 5 6 Clear

1 2 3 Close

0 . **OK** NONE

Help

PLC Station No.

Default Station No.

Address Source

User Input

From Address Lib

System Address


Name	Description
PLC address/station NO.	Set the device station NO. to access. If default station NO. is selected, then the station NO. is the de The station number is the default station number for "Connection" settings in "System Parameters".
User input	The address is not from address library, but a string.
From address Library	The address is selected from address library. If there is no data in address library, it is invalid.

System address	Display all the items of address library. The currently one is the address referenced by the object.
Connection	PLC that already exists in the project.
Address type	The address type or internal register type included in the PLC selected by the project.
Address NO.	To input address NO.
A to F and 0 to 9	To input address NO. through mouse.
Clear	Clear the content of edit box of address.
←	Backspace. To delete the last character of the edit box.
Close	Close address editor
OK	<p>Close the editor and save the editing results.</p> <ul style="list-style-type: none"> <li>• If selecting "From address Library", the result would be saved in the address library</li> <li>• If selecting "User input", the result would be saved in the property of the object</li> </ul>

## Bit lamp

"Bit Lamp" could monitor and display the specified PLC or HMI bit address, and its state changes according to the specified address value.

### Description



**Address:** It is for setting specified PLC or HMI bit address.

## Hide

- **Inverted Display:** Display reverse state of the picture and text. \*for example, the value of write address is set ON, the OFF mode is displayed.
- **Blinking:** Blinking while control bit is triggered, the frequency is editable;
  - Blink when ON: blink when control bit is ON.
  - Blink when OFF: blink when control bit is OFF.
- **Hide:** Display or hide object by "Control Bit" state.
- **Control bit:** For hide control.
  - **Hide mode:** hide when OFF; hide when ON; it could not operate if [Invisible] is checked.
  - **Invisible:** object keeps hidden during project running.

🔗 **Note:** For [text/graphics/animations](#), see the "Bit Switch".

# Word switch

"Word Switch" could change value of specified PLC or HMI word address, when the switch is triggered the value will be written to specified address.

## Description

Word switch

General Text Graphic Security Animation

Edit 1

Read Address 40 Edit

Same read-write address

Write Address 40 Edit

Data Format 2

Format 16-bit unsigned

Mode 3

Set Value  Increase  Decrease

value

Operand 1

Min.Hold Time

Indirect Addressing

Read Address

Write Address

OK Cancel Help

## Edit

- **Read address:** Read value from specified address.
- **Write address:** Write value to specified address.

Read and write address could be the same;

## Data format

- **Format:** It is for setting operating data format; it could support seven modes.

**Mode.** It is for setting operating mode for value, it could support 3 modes.

- **Set value:** Set a constant value for the word address.
- **Increase:** Increase the [operand] value for each time the switch is triggered.
- **Decrease:** Decrease the [operand] value for each time the switch is triggered.
- **High/Low limit:** The value will not increase/decrease when the value reaches limits.


**Note:**

- When 32-bit floating (7 digits) is selected, the operating length is double words.
- For [text/graphics/security/animations](#), see the "Bit Switch".

## Word lamp

"Word Lamp" could display value of specified PLC or HMI word address, the display state of the component changes as the value of the read address changes.

### Description



## Address

- **Read address:** read the value from specified address.

## States settings

- **States count:** The default Word state displays the number of States 1, which could be selected by the drop-down list to display the state of object, range: 1-256.
- **State value:** Users could set different values to correspond to different states, the setting window as below figure shows.


## For example

By default, when value of read address is 0, object displays state 0.

If change settings as below figure shows



When value of read address is 11, object displays state 1.



The image shows a 'State setting' dialog box. It contains a table with two columns: 'State' and 'Value'. The table has six rows, with the first row highlighted in blue. The values are: NO.0 (10), NO.1 (11), NO.2 (12), NO.3 (13), NO.4 (14), and NO.5 (15). To the right of the table is a 'Quick set' section with a 'Start value' input field containing '10' and a 'Set' button. Below this are 'OK' and 'Cancel' buttons.

State	Value
NO.0	10
NO.1	11
NO.2	12
NO.3	13
NO.4	14
NO.5	15


**State of value out of range:** When the value of read address exceeds the maximum state number, there is no corresponding state to be displayed. So there are two modes of processing for it: "Hide" and "Show state"

**Hide:** When the value of the read address exceeds the set range value, the word state display object will be blank.

**Show state:** When the value of the read address exceeds the set range value, the object will display the "Specified state". For example, set the maximum is state 7 (value is 6), when the read address of the value is greater than 6, it will display state 2 text and pictures.

### Transform state

- **Quick Read:** Directly read the value of the connected device without going through the HMI cache
- **Auto transforms:** Object switch states automatically



The image shows a 'Transform state' configuration panel. It contains several options: 'Auto transform' (checked), 'Quick Read' (unchecked), 'Trigger to transform' (checked), 'Auto return' (unchecked), 'Time of transform' (input field with '10' and '\*100ms'), and 'Dynamic time' (unchecked). There is an 'Edit' button next to the 'Trigger to transform' input field.

**Trigger:**Control bit to enable switch automatically

- **Auto return:** return to the initial state after reaching the final state;
- **Time of transform:** it is used for setting the frequency in automatic switching state. Unit: 100ms.
- **Dynamic interval:** set the frequency of automatic switching state and read it from the address. Unit: 100ms. If the value in address is 10, then the frequency of automatic switching state is  $10 \times 100\text{ms} = 1\text{s}$ .

## Manual

Manual

State set       State increase       State decline

Operate state      State 0 ▾

Min. Hold Time


- **Set state:** Set a constant value for the word address.
- **State increase:** Increase state for each time the switch is triggered.
- **State decrease:** Decrease state for each time the switch is triggered.
- **Last state:** The state will not increase/decrease when reaches limits.

🔗 **Note:** For [text/graphics/security/animations](#), see the "Bit Switch".

## Keypad switch

Keypad switch is designed to input data manually; this object need to work with the Keypad. User could assign letters or numbers for each switch, when the switch is triggered the data will input to the textbox.

### Description




1. **Control bit:** This is for control operation, such as "Enter", "Delete", "Clear", "Esc and so on.
2. **Allow input:** It supports input with ASCII character.
3. **Enable Beep:** It is for beep function, enable or disable.

🔗 **Note:** For [text/graphics](#), see the "Bit Switch".

## Function switch

Function switch is designed to switch screens, and call and close sub screen, and transfer data record files.

### Description



## Operation

- **Screen No:** Switch to the selected screen, it could not be sub screen;
- **Open sub screen:** Pop-up selected sub screen, and set sub screen position, default position is (0, 0), this is the coordinates of the top left corner of the screen;

Sub screen position

Position	X	<input type="text" value="0"/>	Y	<input type="text" value="0"/>
----------	---	--------------------------------	---	--------------------------------

- **Previous:** Switch to the previous screen in the screen list;
- **Next:** Switch to the next screen in the screen list;
- **Go back:** Switch to the previous operating screen;

- **Close sub screen:** Close current sub screen;
- **Instalment screen:** Pop-up instalment setting screen, only valid when the instalment is enabled;
- **Flash data to Udisk:** Copy data file from HMI Flash to Udisk, alarm, data record and recipe files could be copied;

Data Type

Alarm record     Data Record     Recipe

- **SD data to Udisk:** Copy data file from SD card to Udisk, alarm and data record files could be copied;

Data Type

Alarm record     Data Record

- **File cache:** Copy the source path file or folder to the specified directory of the destination path;

File cache

Source path    FLASH    data/a.txt

Destination path    USB flash di    data/a.txt

**Using trigger address.** As the figure above,when 00 is ON,then selected operation of the function switch will be executed.

**All terminals effect.** When this function is enabled, all terminals (screens, mobile phones, ipads, computers, etc.) will execute the function Switch Function simultaneously. For example, the screens of each terminal are different. When the screen is clicked to jump to the "Home" screen, all terminals will jump to the home screen.

**Note:**

1. Some special characters like \ : \* ? " <> | are not allowed in file path, otherwise an error (the following characters could not be included in the file name. | >< : \* " ? \) may occur.
2. If you use SD card which HMI doesn't support, then you select the SD card as path,an error may occur.
3. When users save directory ,source path and destination path should end with [/], such as: [data/].
- If source path or destination path is empty, there will be an error: [please set source and destination paths].
- If source path or destination path contain more than two consecutive [/],there will be an error: [invalid path].
4. When users save specified file, it is necessary to set specified file path and file name. Such as: "data/a.txt". If there is no file name in path, there will be an error: "please set source path!" or "Please set destination path!"
5. For [text/graphics/Security/animations](#), see the "Bit Switch".


# Combination switch

The combination switch supports the collection of multiple functions onto one object. When the object is pressed, multiple functions are arranged in sequence to meet the special requirements of user.

The combination switch contains sub-functions such as bit operation, word operation, arithmetic and screen change. Click the corresponding button on the "General" of the object to add sub-functions to the list, and up to 100 sub-functions can be added.

**Note:** there can only be one screen change function in the added sub-functions, and it is at the end of the list).

## Description



## Bit operation

Setting  
Type: Bit copy  
Target bit address  
Source bit address  
Bit address length: 10

It provides "Bit copy", "Set ON", "Set OFF", "Momentary" and "Switch" functions, and it could operate continuous bit addresses according to setting length, and the maximum length is 1024.

**Bit address length:** The length of operated addresses;

Example: "Target bit address" is 00, "Type" is Set ON, the length is 3, when press the button, the 00~02 will be ON.

## Word operation

Setting  
Type: Word set  
Target word address  
operand  
Data Type: 16-bit unsigned  
Word address length: 1

It provides "Word copy", "Word set", "Increase" and "Decrease" functions, and it could operate maximum 2048 word addresses, and the operating length will be changed according to data formats.

- If data format is 16-bit signed (unsigned), the operation address is the source address 0~source address +2048.
- If data format is 32-bit signed (unsigned), the operation address is the source address 0~source address +4096.

**Word addresses length:** The length of operated addresses.

- If "Target word address" is 40, "Type" is Word set, and operand is 10, the length is 3, when press the button, the 40~42 will be 10.

## Arithmetic

Setting	
Type	Add <span>▼</span>
Target word address	340 <span>Edit</span>
Source word address1	444 <span>Edit</span>
<input type="checkbox"/> Constant	
Source word address2	4200 <span>Edit</span>
<input type="checkbox"/> Constant	
Data Type	16-bit unsigned <span>▼</span>

It provides functions such as "Add", "Subtract", "Multiply", "Divide", "Mod" and "Power".

## Screen change

It provides screen switch function as [Function Switch], it supports "Previous", "Next", "Return" and "Change to" operations.

Screen change setting	
Screen change	Next <span>▼</span>
Screen No.	Previous
	Next
	Return
	Change to

## Operation list

"Operations list" displays all operations, HMI will execute operations in order, but [screen switch] will be listed as the last execution item directly.

## Operation button

- **Delete:** Delete selected item function;
- **Empty:** Delete all items in operation list;
- **Up:** Move the selected item up one row in operation list;
- **Down:** Move the selected item down one row in operation list;

## Advanced setting

Control the whole combination switch configuration.



<input checked="" type="checkbox"/> Advanced setting	<input type="text"/>	<input type="button" value="Edit"/>
<input checked="" type="checkbox"/> Bit trigger	<input type="text"/>	
<input checked="" type="checkbox"/> Continuous run		
Cycle time:	<input type="text" value="1"/>	Second
Run times:	<input type="text" value="1"/>	Times
<input type="checkbox"/> Break	<input type="text"/>	<input type="button" value="Edit"/>


- **Bit trigger:** it controls sub-function option of combination switch configuration by trigger address is ON.
- **Continuous run:** it executes each sub-function according to "Cycle time" and "Run times".
- **Cycle time:** Interval between sub-functions execute once with next time.
- **Run times:** Configuration sub-function execute times. 0 means unlimited times.
- **Break:** Stop executing sub-function when trigger address is ON.

#### **Note:**

- Nested patterns of object cycle and sub-function cycles are as follows.
  - The cycle time are independent.
  - The object performs one cycle, all the sub-functions would be performed once.
  - If the object cycle ends earlier than the sub-function cycle, and the sub-function would completes the remaining number of cycles.
  - If the object cycle ends later than the sub-function cycle, and the sub-function cycle would be triggered again.
  - If the main cycle is triggered again before it finishes, then the main cycle is executed immediately when clicked and only one more time.
- For <text/graphics/security/animations>, see the "Bit Switch".

## Slider switch

Slide switch is a special switch object. By changing the position of the slider, the corresponding address value would be changed. At the same time, the slider position will change according to the address value.



### Attributes:

- **Write address:** The address needs to be written and monitored
- **Data format:** Support 16-bit signed / unsigned decimal number, 32-bit signed / unsigned decimal number, floating number is not supported.


### Scale range:

- **Upper/lower limit:** The range of data that can be manipulated by the slider. The value is scaled according to the decimal place of the data format.
- **Variable range:** When this function is checked, the value of the filling address will be used as the upper and lower limits of the scale.
- **Display upper/lower limit:** When this function is checked, the upper and lower limit data will be displayed in the slide switch.

## Function:

- **Direction:** The slide switch provides four directions: from top to bottom, bottom to top, left to right, and right to left.
- **Min. scale:** The minimum scale unit when the slider is moved. The value is scaled according to the format. (Need to drag to move)
- **Scroll value:** The smallest unit of scale when the slider is moved. This value is scaled according to the format. (Need to drag to move)
- **Write address:** Display current value: Show the current value of the device address above the slider
- **Write immediately :** Write the value of the slide switch during the sliding process to the device address in real time.
- **Alarm value:** input the alarm value
- **Alarm color :** When "Alarm color" is ticked off, and the value of the device address reaches "Alarm value", the foreground color of the slide switch will be displayed as a warning color.

🔪 **Note:** Setting the number of decimal place will scale the data range in the data format and it is valid for all kind data formats



### Slide rail

- **Border color:** Tick off to display the border color
- **Foreground color:** The color of the slide rail where the slider slides over. If not checked, the color will be displayed transparently
- **Background color:** The color of the slide rail where the slider does not slide over. If it is not checked, it will be displayed transparently.
- **Height:** slide rail height
- **Shape:** Set the style (right or rounded angle) of the rails

### Slider

- **Color:** Tick off to display the slider color, otherwise it is displayed transparently.
- **Shape:** Set the slider style (square or circle).
  - When circle is selected, need to set the diameter of the slider.

- When square is selected, need to set the height and width of the slider.

The width, height and diameter of the slide rail and slider are displayed as a percentage relative to the height of the object.

- When the slide rail is displayed horizontally
  - The height of the slide rail is displayed as a percentage of the height of the object.
  - The diameter of the circular slider is displayed as a percentage of the height of the object, and it is recommended that the diameter of the slider be greater than or equal to 2 times the height of the slide rail.
  - The width and height of the square slider are displayed as a percentage of the height of the part, and it is recommended that the width of the slider should be greater than or equal to the height of the slide rail.
- When the rails are displayed vertically
  - The height of the slide rail is displayed as a percentage of the width of the part.
  - The diameter of the circular slider is displayed as a percentage of the width of the object, and it is recommended that the diameter of the slider should be greater than or equal to 2 times the width of the slide rail.
  - The width and height of the square slider are displayed as a percentage of the width of the object, and it is recommended that the width of the slider should be greater than or equal to the width of the slide rail.

**Preview:** Display the setting result of slider switch.


🔗 **Note:** For [graphics](#), see the "[Bit Switch](#)".

## Input/Display

This object can input/display number or character. User just needs to set a controller's address and set data format. HMI will be able to display/control controller's data.

### Numeric Input/Display

"Numeric Input/Display" displays the device's data or writes data to the device in a specified numeric format, and the data could be scaled.




## General

- **Read Address:** The data from designated address will be displayed.
- **Input:** Enable input function and "Write Address" configuration.
- **Same read-write address:** Configure [Write Address] is the same as "Read Address".
- **Write address:** Write data to designated address. The address could be different "Read Address".
- **Keypad:** it is standard numeric keypad, allow to input decimal and floating;

🔍 **Note:** Check it to use the comment information on the keyboard. When the user clicks on the part, the comment information will be written into the HUW1402 for display. The maximum length allowed for the comment is 63 characters;

- **Continuous Input:** Use the same keyboard to input the objects from the same Group NO according to the order of NO, and automatically close the keyboard after the last NO(object) is input;
- **NO:** the number of numeric input object;
- **Group NO:** the group number of numeric input object;

## Display



- **Font:** It is located to font list; user could select font directly.
- **Trim 0 display:** The last digit of the decimal only display the non-zero part, such as: 6.30 will be displayed as 6.3.
- **Input as "\*":** the data shown as "\*".
- **Alignment:** There are three modes.
- **Center:** data display on the center of object.
- **Align left:** data display on the left.
- **Align right:** data display on the right.

## Data format

Data format

Data: 16-bit unsigned Word: WORD

Data format: Max.digits: 5 Integer: 5 Decimal digits(D): 0

Range: Data range: 0-65535 Low limit(I): 0 High: 65535

Note: Only hexadecimal keypad available for binary, octonary, hexadecimal data.

OK Cancel

Data format	
16-bit unsigned	Setting
0 - 65535	
Integer: 5 Decimal: 0	

- **Date:** Select data format, below format could be supported.

- 16-bit unsigned
- 16-bit binary
- 16-bit octal
- 16-bit Hex
- 16-bit BCD
- 16-bit signed
- 16-bit unsigned
- 32-bit binary
- 32-bit octal
- 32-bit Hex
- 32-bit BCD
- 32-bit signed
- 32-bit unsigned
- 32-bit floating
- 64-bit double

- **Data format:** Configure data display format.
- **Range:** beyond the data range will be not inputted.



### **Keypad position**

It is used for setting keypad position when input data.

### **Label**

Configure label shown on the left/ right side of data.


### **🔍 Note:**

- The significant digits of a single-precision float are 7 digits.
- For [graphics/security/animations](#), see the "Bit Switch".

## **Character Input/Display**

"Numeric Input/Display" displays the device's character or writes character to the device.

### **Description**



## General

- **Read Address:** The data from designated address will be displayed.
- **Input:** Enable input function and "Write Address" configuration.
- **Same read-write address:** Configure "Write Address" is the same as "Read Address".
- **Read DWord:** Read address is 2 words format
- **Write address:** Write data to designated address. The address could be different "Read Address".
- **Keypad:** it is standard numeric keypad, allow to input decimal and floating;

🔍 **Note:** Check it to use the comment information on the keyboard. When the user clicks on the part, the comment information will be written into the HUW1402 for display. The maximum length allowed for the comment is 63 characters;

- **Continuous Input:** Use the same keyboard to input the objects from the same Group NO according to the order of NO, and automatically close the keyboard after the last NO (object) is input.
- **NO:** the number of numeric input object.
- **Group NO:** the group number of numeric input object.

🔍 **Note:** The Continuous Input function will be invalid if the Confirmation function is enabled.

## Display

- **Input as "\*":** the data shown as "\*".
- **Alignment:** There are three modes.
- **Center:** data display on the center of object.
- **Align left:** data display on the left.
- **Align right:** data display on the right.
- **Exchange high-low byte:** Exchange High-low byte: Check it to exchange and display the contents of the high and low bytes. If the number of contents is not a multiple of 2, the rounding process will be performed.
- **Length:** The length for characters, the maximum length is 256.
- **Exchange high-low word:** Check it to exchange and display the contents of high and low word. Only valid if the number of operating characters of the part is a multiple of 4.

## Keypad position

It is used for setting keypad position when input data.

🔍 **Note:** For [graphics/security/animations](#), see the "Bit Switch".

# Chart

Chart can display the data by trend graph or data table. PIStudio supports different function's Chart. It contains Trend Chart, History Trend Chart, Alarm Record Display, Data Record Display, Alarm Record Display, Recipe Display, List Box, File List Display, XY Plot, History XY Plot. Different chart has different function. Please check the detail information in the Help of PIStudio.

For example: Trend graph shows the data as a dynamic curve, the X axis represent the time, Y axis represent the data. Alarm Record Display record alarm, the time span set by the user, and the alarm record will list by the time sequence.

## Common settings

### Introduction

This section will introduce common settings in Chart objects

## Shape

Shape	
Background color	<input type="color" value="#ADD8E6"/>
Head color	<input type="color" value="#008080"/>
Text color	<input type="color" value="#000000"/>
Line color	<input type="color" value="#008080"/>
Select line color	<input type="color" value="#9ACD32"/>
Coordinate	<input type="button" value="Set"/>

Set appearance of object, includes background color, head color, text color, line color, select row color

## Advance

<input checked="" type="checkbox"/> Advance	
Head text color	<input type="color" value="#000000"/>
Transparency	<input type="text" value="Opaque"/> ▾
Cell type	<input type="text" value="Adaptive"/> ▾
Date format	<input type="text" value="yyyy-mm-dd"/> ▾
Time format	<input type="text" value="HH:MM:SS"/> ▾

- **Head text color:** It sets the text color of the header.
- **Transparency:** It sets transparency of the table background, 0% represents full transparency, and 100% represents completely opaque.
- **Cell type:** Default is adaptive width. After select a customization, customization could set the width of the cell.
- **Date and time format:** According to the needs to select the date and time display format. "NONE" means no display; please do not set both time and date to "NONE".

## Function start address

Instructions for the use of the function start address of record display/alarm display/trend charts etc.

Query setting	
<input checked="" type="checkbox"/> Use function address	
Function address(20 words)	<input type="text" value="HDW0"/> <input type="button" value="Edit"/>
Function screen	<input type="text" value="4001"/> ▾ <input type="button" value="New Screen"/>
Address and screen should be different from other object	

The address you fill in is only as the start address. This address, including 20 consecutive addresses after this address, will be occupied. Please organize your address to prevent unnecessary errors from being reused.

**For example,** HDW0 is the function start address, then the addresses HDW0 to HDW19 are occupied. IF you need the power-down storage setting, you may set the address as the address of register HAW (HAW0 to HAW200000).

If the start address set as HDW0, the function and address table is as below.

Address	Type	Object	Function
HDW0	Word	Numeric input	Start Time: Year
HDW1	Word		Start Time: Month
HDW2	Word		Start Time: Day
HDW3	Word		Start Time: Hour
HDW4	Word		Start Time: Minute
HDW5	Word		Start Time: Second
HDW6	Word		Span value setting. Unit view the next address
HDW7	Word		Span Unit: 0=Min, 1=Hour, 2=Day
HDW8	Word	Word Switch	Default as 1. It can contain 50 records per page Page Up : Current Value minus 1. Page Down : Current Value add 1. Range: 1 to 65535
HDX9.0	Bit	Bit Switch	Auto Refresh

HDW12 (Bit address control up and down left and right display)	HDW12.0		Table type object: Move one page up History Trend Chart: Pop up query settings window	
	HDW12.1		Table type object: Move one row up History Trend Chart: Move one span down	
	HDW12.2		Table type object: Move one page down History Trend Chart: Move one span up	
	HDW12.3		Table type object: Move one row down History Trend Chart: Display/Hide slide bar	
	HDW12.4		Table type object: Move one page left History Trend Chart: Zoom in (Narrow time span down)	
	HDW12.5		Table type object: Move one column left History Trend Chart: Zoom out (Broaden time span up)	
	HDW12.6		Table type object: Move one page right	
	HDW12.7		Table type object: Move one column right	
HDX13.0	Bit	Numeric Input	Span Method : =0: Use the Span Value and Span Unit to query; =1: Use start time and end time to calculate the time span for query.	
HDW14	Word		Effective when HDX13.0=1	End Time: Year
HDW15	Word			End Time: Month

HDW16	Word			End Time: Day
HDW17	Word			End Time: Hour
HDW18	Word			End Time: Minute
HDW19	Word			End Time: Second

**Note:**

- [Function address (20 words)] need to be HMI internal address;
- When the start time and end time of the query are enabled, if the end time is smaller than the start time, the system automatically swaps the start and end times to calculate the span of the query;
- After manually setting the start time and end time of the query, you need to manually update the data (the default will be automatically updated);

**Appearance**

Background Type	3	
Transparence	Opaque	
Position		
X	18	Y 63
Size		
W	751	H 404

- **Background type:** There are four modes, style 1 and style 2 is gradient mode, style 3 is solid color mode, style 4 is transparent.
- **Transparency:** transparency could be set from 0% to 100%. when set to 0%,the background is completely transparent.
- **Position:** Show position coordinates for X and Y axes.
- **Size:** Set object size.

Source	Appearance	Range	Function
X Grids		5	
Y Grids		5	
<input type="checkbox"/> Show dat			
<input type="checkbox"/> Use font			
Date format		yyyy-mm-dd	
Time format		HH:MM:SS	
Time type		1	
			Background Color1
			Background Color2
			Grid Color
			Scale Color
			Scale Value Color
			<input type="checkbox"/> Show slider

- **Number of X,Y axis:** Set the number of grids on the XY axis could be set from 1 to 10 divisions.
- **Color setting:** Color1 is for object frame;color2 is for grid background.
- **Show dot:** Display the data points of each trend graph.
- **User font:** If check it, user could change the font for grid and time, if uncheck it, object uses build-in font.
- **Grid color:** Set color for grid, the default is black.
- **Scale color:** Set color for scale, the default is black.
- **Scale value color:** Set color for scale value, the default is black.
- **Data format:** select data format in object, it provides below format.

Date format	yyyy-mm-dd
Time format	yyyy-mm-dd dd-mm-yyyy mm-dd-yyyy dd.mm.yyyy NONE
Time type	

**Time format:** Select time format in object, it provides below format.

Time format	HH:MM:SS
Time type	HH:MM:SS HH:MM NONE

- **Time type:** There are two time displaying type, one is only displaying the start and end time, and the other is displaying time for each cell.
- **Curve Fitting (XY)**
- **Line type:** Set the line type (line, curve) between two points.
- **Smoothness:** it sets the smoothness of curve. Smoothness sets the curve smoothness. Conversely, the corner of the curve is sharper.








# Real-time trend chart

Trend graph shows the data as a dynamic curve, X axis represent the time span, Y axis represent the data.

## Source

- **Curve buffer:** Select data from and display data in term of curve.
- **Curve displays:** HMI will display curves according to select "Trend Chart", and user could select which curves need to be displayed and select "Line type" and "Color" for each curve.

Curve	Line Type	Color
<input checked="" type="checkbox"/> 1	—————	Red
<input checked="" type="checkbox"/> 2	—————	Yellow
<input type="checkbox"/> 3		
<input type="checkbox"/> 4		
<input type="checkbox"/> 5		
<input type="checkbox"/> 6		
<input type="checkbox"/> 7		
<input type="checkbox"/> 8		

Source	Appearance	Range
X Grids	5	▼
Y Grids	5	▼
<input checked="" type="checkbox"/> Show dat		
<input checked="" type="checkbox"/> Use font		
Date format	yyyy-mm-dd	▼
Time format	HH:MM:SS	▼
Time type	1	▼
Background Color1		
Background Color2		
Grid Color		
Scale Color		
Scale Value Color		

## Range

Set data range limit of curve (max and min). Also, could set variable to control data range.

Source	Appearance	Range
<input checked="" type="checkbox"/> Variable		
Data format:		<div style="border: 1px solid black; padding: 2px;">           32-bit signed ▼            16-bit BCD            16-bit signed            16-bit unsigned            32-bit BCD            32-bit signed            32-bit unsigned            32-bit floating         </div>
Y Limit		
Y high limit address		
Y low limit address		

**Note:** For the setting of Real-time trend chart, please refer to "[Trend chart](#)"

## History trend chart

The history trend will display data record with graph. X axis represents as time, and Y axis represents as data.

### Source

- **Curve buffer:** Select data from "Data record", and display data in term of curve.

- **Curve displays:** HMI will display curves according to select "Data record", and user could select which curves need to be displayed and select "Line type", "Color" and select "Channel" for each curve.

History Trend Chart
✕

Background Type 3 ▾

Transparence Opaque ▾

Position

X 256 Y 33

Size

W 46 H 47

Source Appearance Range Function

Curve buffer Record No.:-1 Set

Use	Line Type	Color	Channel
<input checked="" type="checkbox"/> 1	—————		
<input checked="" type="checkbox"/> 2	—————		
<input type="checkbox"/> 3			
<input type="checkbox"/> 4			
<input type="checkbox"/> 5			
<input type="checkbox"/> 6			
<input type="checkbox"/> 7			
<input type="checkbox"/> 8			

OK
Cancel
Help

**Range**

Set data range limit of curve (max and min). Also could set variable to control data range;


**Function**

Source	Appearance	Range	Function
Start Addr:	<input type="text"/>	<input type="button" value="Edit"/>	
Screen	<input type="text" value="v"/>	<input type="button" value="Add screen"/>	
<input checked="" type="checkbox"/> Use Dynamic channel			
Channel Addr(8words):	<input type="text"/>	<input type="button" value="Edit"/>	
Start time	<input type="text" value="Current time"/>	<input type="button" value="v"/>	
Span	<input type="text" value="1"/>	<input type="text" value="Day"/>	<input type="button" value="v"/>








- **Start address:** Custom object for query function, HMI system assigns address according to the settings, and four control key and query screen will be created, user could see the query details in this query screen.
- **Use Dynamic channel:** It occupies 8 addresses; each address corresponds to the curve channel number. For example, the address is set to HDW10, it takes up HDW10 to HDW17. Where the value of HDW10 is 3, then the first curve in the trend graph shows the value of channel 3.
- **Start time:** Set start time and span for curve display.

## Result

When all configurations are completed, when the HMI is running, it displays as shown below.



There are 8 buttons will display in below the graph, shown as following.

1.  : Historical trend chart query button
2.  : Set the time and span of historical trend chart
3.  Refresh
4.  : Move forward by span time
5.  : Move backwards by span time
6.  : Slider display control button, slider position can display the current time and the current numerical status of each curve.
7.  : Zoom in by one time according to the length of the span.



8. :Zoom out by one time according to the length of the span.

**Note:** For the setting of historical trend chart, please refer to "Trend chart".

## Alarm record display

Display current alarm and history alarm information. After setting the time span, the history alarm record will list by the time span.

This object only displays content normally after the "Alarm Record" function is set.

Alarm record display
✕

**General**

**Shape**

Background color

Head color

Text color

Line color

Select line color

Coordinate Set

**Setting 1**

Alarm Type History alarm record

Group No. 0 ~ 255

Display in reverse order

Alarm Record Setting

**Query setting 2**

Use function address

Function address(20 words) HDW0 Edit

Function screen 4001: New Screen

Address and screen should be different from other object

**Start Time 3**

Current Time

Before Now 1 Hour

Today 1 Hour

Yesterday 1 Hour

This Month 1 Day

Last Month 1 Day

Span 1 Hour

Advance

Head text color

Transparence Opaque

Cell type Adaptive

Date format yyyy-mm-dd

Time format HH:MM:SS

OccurrenceTime	ID	CurrentValue
2016-10-25 12:30:40	Alarm1	20
2016-10-25 12:30:40	Alarm2	21

OK
Cancel
Help



**Page control:** it controls what object currently displays.

**For example:** Page control is 40,

- 40=1 means this object displays first page.
- 40=2 means this object displays second page.
- 40=3 means this object displays third page.
- ...
- 40=10 means this object display 10th page.

**Note:** Every page contains 50 records.

### Start Time

It configures start query time and span.

Start Time

Current Time

Before Now  Hour

Today  Hour

Yesterday  Hour

This Month  Day

Last Month  Day

Span  Hour

**Span:** set the time span from start time to end time of query.











### Result

When all configurations are completed, when the HMI is running, alarm display object displays as shown below.

The query key is automatically displayed when user double-clicks object, and the system automatically generates a sub-screen that sets the query span.



OccurrenceTime	ID	CurrentValue	AlarmT
2019-06-18 11:08:48	1	0	too low
2019-06-18 11:09:29	2	0	too low
2019-06-18 11:10:10	3	0	too low
2019-06-18 11:10:51	4	0	too low
2019-06-18 11:11:32	5	0	too low
2019-06-18 11:12:13	6	0	too low
2019-06-18 11:12:54	7	0	too low
2019-06-18 11:13:35	8	0	too low
2019-06-18 11:14:16	9	0	too low
2019-06-18 11:14:57	10	0	too low
2019-06-18 11:15:38	11	0	too low
2019-06-18 11:16:19	12	0	too low

-  Query setting
-  Refresh page
-  means moving up one row;
-  means page up.
-  means moving down one row;
-  means page down.
-  means moving left column;
-  means moving the display to the left.
-  means moving right column;
-  means moving the display to right.

**Note:** Please click here to set "[Bit alarm](#)" and "[Word alarm](#)".

## Data record display

"Data Record Display" displays the value of the address set by the user in the data record in the form of a table. It provides the function of query. You could query all the recorded data within a specified period. If the project does not edit data recorded area or there is no historical data, data record would display nothing. You can dynamically set the query period on the HMI and save the power failure.

**Note:** The objects such as tables and trends charts are only support "song typeface". It is invalid if you set other fonts.

This object only displays content normally after the "[Data record](#)" function is set.

**Data record display**

General Security **4**

Shape setting

Background color

Head color

Text color

Line color

Select line type

Coordinate  Set

Advance

Head text color

Transparency  ▾

Cell type  ▾

Date format  ▾

Time format  ▾

Record **1**

▾ Set Group

Func Address(20 words)

Edit

Screen(one object one screen)

▾ Add screen

Display in reverse order **2**

Start time **3**

Current time

Forward  Hour ▾

Today  Hour

Yesterday  Hour

This month  Day

Last month  Day

Span  Hour ▾

Time	Name	Operator	AlarmText

OK Cancel Help

## Record

There are data of multiple groups could be set in the data record, but it could only display the data of one group at the same time. Therefore, during configuring, user need to specify the corresponding data record group number for each object.




The image shows a configuration box titled "Record". It contains a dropdown menu with the number "1" selected and a "Set Group" button to its right.

## Display in reverse order

It sorts by time by default. The oldest data record will be displayed at the top of it. If you check "Display in reverse order", the latest data record will be displayed at the top.


## Start Time



The image shows a configuration box titled "Start Time". It has several radio button options: "Current Time" (selected), "Before Now", "Today", "Yesterday", "This Month", and "Last Month". To the right of each option is a text input field containing the number "1" and a unit dropdown menu. The units are "Hour" for "Before Now", "Today", "Yesterday", and "Span"; and "Day" for "This Month" and "Last Month".

You can configure the start query time. Set the time span from start time to end time of query.

## Security



The image shows a configuration box with two tabs: "General" and "Security". The "Security" tab is active. Under the heading "Table display", there are two checked checkboxes: "Channel control address (8 words)" and "Freeze first column". Below the first checkbox is a text input field and an "Edit" button.









- **Channel control address:** It continuously occupies 8-word addresses, the first 100-bit addresses control 100 channels of display/hide function. For example, if the address is set to HDW10, then HDX10.0=1 is hidden channel 1; HDX10.1=1 is hidden channel 2, and so on.
- **Freeze first column:** Enable it, the first column (time column) of the data record will not move with the left and right pages.



For details about "function address", see "[Common settings in chart objects](#)".

The query key is automatically displayed when user double-clicks object, and the system automatically generates a sub-screen that sets the query span. When all configurations are completed, when the HMI is running, data record display object displays as shown below.

### Data record function

Time	Channel1	Channel2	Ch
2019-06-18 15:08:33	0	0	0
2019-06-18 15:08:43	50	0	0
2019-06-18 15:08:53	100	0	0
2019-06-18 15:09:03	150	0	0
2019-06-18 15:09:13	200	0	0
2019-06-18 15:09:23	45	0	0
2019-06-18 15:09:33	95	0	0
2019-06-18 15:09:43	145	0	0
2019-06-18 15:09:53	195	0	0
2019-06-18 15:10:03	40	0	0
2019-06-18 15:10:13	90	0	0

-  Query setting: It is on the bottom right of corner. Click it, a sub-screen of query range would pop-up to set.
-  Refresh the query results.
-  Move one row up in the query range
-  Move one page up in the query range
-  Move one row down in the query range
-  Move one page down in the query range
-  Move one row left in the query range
-  Move one page left in the query range

-  move one row right in the query range
-  move one page right in the query range


For details about the setting, please refer to "[Data record display settings](#)".

## Recipe display

"Recipe display" displays information (such as recipe, operations, and so on) in the form of a table.

This object not only displays the recipe, but also displays other content. The specific functions are described in detail later. And it only displays content normally after function is set.

**There are 8 types of operating files as follows. Except for recipe file, the other types are used for special purpose.**



### Function (Recipe File)

- **File type:** There are more than one function in this object, this is for selecting function, select "Recipe File", when "Recipe function" is set, it will display recipe data in the form of a table.
- **Folder name:** This is located to recipe function setting.
- **Select line:** Select one line in list and display its line No. in this address. (Note : When the file type is Recipe File, modify the address value to control the selected line of the list to jump to the corresponding line; for other file types, this address only has the effect of displaying the line No.)
- For example, set 40,
  - if 40=1, the first row of object is selected.
  - If 40=2, the second row of object is selected.
  - ...
  - If 40=10, the 10th row of object is selected.
- **Folder name address:** This is for setting recipe file name, in advance recipe mode.

Function

File type Recipe File ▾

Folder name Test ▾

Select line  Edit

Folder name address

Address control

Start group  Edit

Group  Edit

Start member  Edit

Member  Edit

### Function (Operating Record)

Function

File type Operating Record ▾

Select line 40 Edit

- **File type:** There are more than one function in this object, this is for selecting function, select [Operating Record], when [User Permission] is enabled, the operation record of each user in HMI is recorded and displayed in the form of a table, and the time and date display format could be set as needed.
- **Select line:** Set address for select row.

### Function (Timeout Alert)

Function

File type

Select line

- **File type:** There are more than one function in this object, this is for selecting function, select [Timeout], it displays the current HMI project communication timeout information. (The built-in screen has this special function; it will pop up automatically when timeout, users do not need to set).
- **Select line:** Set address for select row.

### Function (Client Manage)

Function

File type

Select line

- **File type:** There are more than one functions in this object, this is for selecting function, select [Client manage], it displays the current visitors' screens information.
- **Select line:** Set address for select row.

### Function (User Manage)

Function

File type

Select line

Refresh

- **File type:** There are more than one functions in this object, this is for selecting function, select [User Manage], when [User Permission] is enabled, it displays all users' information.



- **Select line:** Set address for select row.
- **Refresh:** Set address for refresh users list; (bit address).

### Function (System Message)

The screenshot shows a configuration window titled 'Function'. Inside, there is a 'File type' dropdown menu currently set to 'System Message'. Below this, there is a 'Select line' text input field and an 'Edit' button to its right.

- **File type:** There are more than one functions in this object, this is for selecting function, select [System message], when event occurs, it displays prompt messages automatically.
- **Select line:** Set address for select row.

### Address Control

- **Start group:** control displaying start from specified row, which means display from specified group.
- For example set 40,
  - If 40=1, Start from first row (first group).
  - If 40=2, Start from second row (second group).
  - ...
  - If 40=10, Start from 10th row (10th group).
- **Group number address:** Control the number of rows displayed;
- For example set 410,
  - If 410=1, this object only displays 1 row (1 group).
  - If 410=2, this object displays 2 rows (2 groups).
  - ...
  - If 410=10, this object displays 10 rows (10 groups).
- **Start address:** Control displaying start from specified column, which means display from specified member.
- For example, set 420,
  - If 420=1, Start from first column (first member).
  - If 420=2, Start from second column (second member).
  - ...
  - If 420=10, Start from 10th column (10th member).
- **Address number:** Control the number of columns displayed.
- For example, set 430,
  - If 430=1, this object only displays 1 column (1 member).
  - If 430=2, this object displays 2 columns (2 members).
  - ...



## Client Manage

### User Permission

ID	Name	PassWord	Description
1	Manager	wecon123	user0
2	Tech	wecon234	user1
3	worker	wecon345	user2

#### Note:



- If the file type is recipe file, modify the value of the address of "Select line" to control the selected line in the display list to the corresponding line. If another file type is selected, this address can only display the selected line (read-only mode).
- For ie series and ig series HMI, "system message" and "timeout alert" will be displayed in the top pop-up window. They options of them will no longer be displayed in the record.
- For the details, please refer to "[Recipe](#)".

## File list

"File List" displays the recipe file name of the current project in the form of table in HMI. If there is no recipe file in the project, the table of the object is empty. (Table and trend chart objects currently only support Song Typeface, other fonts you set will not work.

recipe files in "Flash", and also shows custom folder information.

### Function (Recipe File)



- **File type:** [Recipe File] is for display recipe files in Flash.
- **Folder name:** This is located to recipe function setting.
- **Select line:** Select one line in list and display its line No. in this address.
- For example, set 40,

- if 40=1, the first row of object is selected.
- If 40=2, the second row of object is selected.
- ...
- If 40=10, the 10th row of object is selected.

🔍 **Note:** When the file type is Recipe File, modify the address value to control the selected line of the list to jump to the corresponding line; for other file types, this address only has the effect of displaying the line No.

- **Folder name address:** This is for setting recipe file name, in advance recipe mode.

### Function (Custom Folder)

Function	
File type	Custom folder
Root	Flash
Folder	recipe
Select line	40
Folder name address	410

- **File type:** The object displays files under the specified path.
- **Root:** It means storage; there are three options, "Flash", "Udisk" and "SDcard".
- **Folder:** Set folder name, such as recipe.
- **Select line:** Set address for select row.
- For example, set 40,
  - if 40=1, the first row of object is selected.
  - If 40=2, the second row of object is selected.
  - ...
  - If 40=10, the 10th row of object is selected.
- **Folder name address:** This is for setting recipe file name, in advance recipe mode;

### Use function address (20 words)

<input checked="" type="checkbox"/> Use function address(20 words)	
Function address	HDW90

Function address includes copy, past, delete and rename. And HMI automatically assigns the functions to bit addresses.

For example, if the function address is HDW 90, the detailed information as below.

Address	Address type	Object type	Function
HDX90.0	Bit	Bit switch (ON)	Copy selected files / all files
HDX90.1	Bit		Paste selected files/ all files
HDX90.2	Bit		Delete selected files/ all files
HDX90.3	Bit		Select all files
HDX90.4	Bit		Rename select files (Do not include suffix)
HDX90.5	Bit		Rename select files (Include suffix)

Using this function address can realize that copy a file of one file list to another file list. For example, the recipe file of flash (file list A) is copied to the recipe file of the U disk files in the file list (B), and the file name will be copied too. You could rename it with the "rename" address.

### Result


When all configurations are completed, when the HMI is running, it displays object displays as shown below.



**Note:** For the details, please refer to "Recipe".

### XY plot

It reads a continuous value of PLC register, converts the read value according to the specified data format, and displays as XY trend chart on HMI.



## Source

- **Auto Sample:** Select data from [XY plot] and displayed in a curve according to the set time.
- **Trigger Sample:** When the trigger address is set, the data is collected and displayed in a curve. After the data is collected, the trigger address is automatically reset.

**Curve settings:** According needs to set style and color for each curve.






**Read address:** \*for example, PLC word address is D, it points number is m. (point numbers no more than 800).

- Word address D is the X coordinate of the first point.
- Word address D+1 is the Y coordinate of the first point.
- Word address D+2 is the X coordinate of the second point.
- Word address D+3 is the Y coordinate of the second point.
- .....

- Word address  $D+2m-1$  is the X coordinate of the  $m^{\text{th}}$  point.
- Word address  $D+2m$  is the Y coordinate of the  $m^{\text{th}}$  point.

Because if the number of XY points is  $m$ , it is necessary to continuously read  $2m$  words from the address  $D$  of the PLC to draw a complete XY picture.

## Appearance

Source	Appearance	Range
X Grids	5	▼
Y Grids	5	▼
<input checked="" type="checkbox"/> Show dat		
<input checked="" type="checkbox"/> Use font		
<input checked="" type="checkbox"/> Only Y value		
Line type	Line	▼
Background Color1		
Background Color2		
Grid Color		
Scale Color		
Scale Value Color		

- **X grids and Y grids:** The range is from 1 to 10.
- **color setting:**
  - Background color 1 indicates the background color of appearance.
  - Background color 2 indicates the background color of grid.

## Range



Source	Appearance	Range
<input checked="" type="checkbox"/> Variable		
Data format:		32-bit signed
Y Limit		
Y high limit address	<input type="text"/>	Edit
Y low limit address	<input type="text"/>	Edit
X Limit		
X high limit address	<input type="text"/>	Edit
X low limit address	<input type="text"/>	Edit

- **Variable:** The data range for the graph could be set as a variable.
- **X, Y Limit:** Set the max and min value of displaying curve.

## Result


When all configurations are completed, when the HMI is running, it displays as shown below.



**Quick setting:** Fill in the starting address, according to the parameter settings, automatic allocation of addresses.

# History XY plot

The data in cache will display as continuous curve or separated points, each point in XY plot needs 2 addresses to set a point.



## Source






- **Auto Sample:** Select data from [XY plot] and displayed in a curve according to the set time.
- **Trigger Sample:** When the trigger address is set, the data is collected and displayed in a curve. After the data is collected, the trigger address is automatically reset.

**Curve settings:** According needs to set style and color for each curve.

- **Read address:** \*for example, PLC word address is D, it points number is m. (point numbers no more than 800).
  - Word address D is the X coordinate of the first point.
  - Word address D+1 is the Y coordinate of the first point.
  - Word address D+2 is the X coordinate of the second point.
  - Word address D+3 is the Y coordinate of the second point.
  - .....
  - Word address D+2m-1 is the X coordinate of the m<sup>th</sup> point.
  - Word address D+2m is the Y coordinate of the m<sup>th</sup> point.

Because if the number of XY points is m, it is necessary to continuously read 2m words from the address D of the PLC to draw a complete XY picture.

### Appearance

Source	Appearance	Range
X Grids	5	▼
Y Grids	5	▼
<input checked="" type="checkbox"/> Show dat		
<input checked="" type="checkbox"/> Use font		
<input checked="" type="checkbox"/> Only Y value		
Line type	Line	▼
Background Color1		
Background Color2		
Grid Color		
Scale Color		
Scale Value Color		


- **X grids and Y grids:** The range is from 1 to 10.
- **color setting:**
  - Background color 1 indicates the background color of appearance.
  - Background color 2 indicates the background color of grid.

### Range

Source	Appearance	Range
<input checked="" type="checkbox"/> Variable Data format: <span style="border: 1px solid gray; padding: 2px;">32-bit signed</span>		
<b>Y Limit</b> Y high limit address <span style="border: 1px solid gray; display: inline-block; width: 100px; height: 20px;"></span> <span style="border: 1px solid gray; padding: 2px 5px;">Edit</span> Y low limit address <span style="border: 1px solid gray; display: inline-block; width: 100px; height: 20px;"></span> <span style="border: 1px solid gray; padding: 2px 5px;">Edit</span>		
<b>X Limit</b> X high limit address <span style="border: 1px solid gray; display: inline-block; width: 100px; height: 20px;"></span> <span style="border: 1px solid gray; padding: 2px 5px;">Edit</span> X low limit address <span style="border: 1px solid gray; display: inline-block; width: 100px; height: 20px;"></span> <span style="border: 1px solid gray; padding: 2px 5px;">Edit</span>		

- **Variable:** The data range for the graph could be set as a variable.
- **X, Y Limit:** Set the max and min value of displaying curve.

**Result:** When all configurations are completed, when the HMI is running, it displays as shown below.




**Note:** For the setting details, please refer to "[History XY plot](#)".

## Disc record chart

The Disc Record displays the data from data source in the form of a disc curve.

**Note:** This function are only supported by HMI+, i series, ie series and ig series.

## Source



- **Source type**

- **History:** Historical data can be queried.
- **Real Time:** Only real-time data is displayed.

- **Curve Buffer**

- **History:** It is in data record area configured by data record. Multiple record groups could be configured, and each record group has multiple channels.

- **Real Time:** It is in Real-time trend chart configured by data record. Multiple record groups could be configured, and each record group has multiple curve numbers.

🔪 **Note:** There must be one of settings (Data record and real-time trend chart) in configurations, otherwise there will no data in curve buffer.

- **Curve No.:** The number of curves is the same as the number of channels in the record group. A maximum of 8 curves could be displayed. After selecting the curve to be displayed, it can set the scale range and scale color of each curve.
- **Enable:** After selecting the corresponding curve number in the status bar and enable the curve, set different curve styles and colors according to your needs, then select the channel number in the data buffer, and finally set the data range.
- **Data Range:** Directly set the maximum and minimum values of the displayed graph. If the box "Variable Range" is checked, the set data is read from the filled address. The data format of the address is set as needed, and the length of the variable address is related to the set data format.
- **Display Scale Value:** Display the value of disc record. The font color could be changed

## Appearance

Source	Appearance	Function
Circular Axis Scale	<input type="text" value="5"/>	Background Color <input type="color" value="#00FF00"/>
Start Position	<input type="text" value="Up"/>	Inner Circle Color <input type="color" value="#FFFFFF"/>
Rotary Axis Scale	<input type="text" value="4"/>	Outer Circle Color <input type="color" value="#FFFFFF"/>
Inner Circle Size	<input type="text" value="20"/>	Grid Color <input type="color" value="#D3D3D3"/>
Scale Style	<input type="text" value="0"/>	Scale Color <input type="color" value="#000000"/>
Date Format	<input type="text" value="yyyy-mm-dd"/>	<input type="checkbox"/> Enable Font
Time Format	<input type="text" value="HH:MM:SS"/>	<input type="checkbox"/> Enable Point

1. **Circular Axis Scale:** Number of scale intervals in the direction of the circular axis. The range is 1 to 10.
2. **Start Position:** The starting position to draw the curve: top, bottom, left and right.
3. **Rotary Axis Scale:** Number of scale intervals in the direction of the axis of rotation. The range is 4, 6 and 12.
4. **Inner Circle Size:** Ratio of the inner circle to the outer circle.
5. **Scale Style:** The way the scale is displayed, style 0 represents adaptive display, and style 1 represents forward display.
6. **Background Color:** Appearance background color.
7. **Inner Circle Color:** The inner circle color in the drawing area of the Disc.
8. **Outer Circle Color:** The outer circle color in the drawing area of the Disc.
9. **Grid Color:** Grid line color.
10. **Scale Color:** Color of the time scale and tick marks.

11. **Data Format & Time Format:** Configure the display mode of the time and date as required, where NONE means no display. It is forbidden to set both the time and date display to NONE, and when the date is set to NONE, the day parameter can be set in the time.
12. **Enable Font:** Use the set font library and font size for display. When this font is not enabled, the default built-in font is used for display.
13. **Enable Point:** Set to enable point, the data unit of each curve will be highlighted as a point.

## Function

The screenshot shows the 'Function' configuration panel. It has three tabs: 'Source', 'Appearance', and 'Function'. The 'Function' tab is active. The panel is divided into two main sections. The top section contains 'Start Addr:' with a text input field containing 'HAW0' and an 'Edit' button, and 'Screen' with a dropdown menu showing '4001:' and an 'Add screen' button. The bottom section contains 'Start time' with a dropdown menu showing 'Current time' and 'Span' with a text input field containing '1' and a 'Day' dropdown menu.

**Function start Address:** Open the sub-screen of the data record query, and the system can automatically allocate the object address of the query screen according to the configured address. When using this component, it will automatically generate buttons for four direction, you can use these four control keys to view the data record display, and automatically create a new sub-screen based on the function start address, the content of the sub-screen is the query setting for span and start time.

When two objects use one function screen at the same time, if the function addresses of the two object are the same, changing the built-in screen will affect the operation of the two display object at the same time. If the function addresses of the two objects are different, the second object with the built-in screen can be displayed normally, and the first object will be displayed abnormally.


**Note:** When copying Data record display, it is recommended to create a new "function screen" to avoid repeated calls that may cause abnormal functions.

**Start time:** Set the start time and conditions for data viewing.

For the description of the start address of the function, please refer to [Common settings in chart objects](#).

For the setting, please refer to [8.3 Data Record](#).

## Meter




## Pointer meter

The meter responds to changes in the value of the indicated word address by means of a dial and a pointer. The meter looks very similar to the actual meter.



**Meter** [X]

**Graphic**



Read address: [ ] [Edit]

Data format: 16-bit unsigned [v]

Digits setting: 5.0 [Edit]

Variable Limits

Min angle: 0 [Set]

Max angle: 100 [Set]

Show meter background

Type: 1 [v]

Show pointer

Type: 1 [v] Pointer color: [Red]

Show alarm area

Count: 1 [v] Refresh alarm area [Button]

Alarm value1: 0 [ ] 100 [ ] Color1: [Black]

Show scale

Major scale: 5 [v] Major color: [Black]

Minor scale: 10 [v] Minor color: [Black]

Scale value: 1 [v]

Meter type: 270° [v] Start angle(°): 0 [ ]

Position: X: 108 [ ] Y: 385 [ ]

Size: Width: 47 [ ] Height: 47 [ ]

[OK] [Cancel] [Help]

**Read address:** Read the value from the set PLC address.

**Data format:** It is for data setting. The data format types are as below.

- BCD, 32-bit float
- signed decimal
- unsigned decimal
- 32-bit signed decimal
- 32-bit unsigned decimal

**Digits setting:** set directly the maximum and the minimum. Only when the floating point number is selected, can the maximum and minimum value be with a decimal point, and other data format can't be with a decimal point. If the value is read by the address, then select "variable limits", and fill in the address.

- **Min angle and max angle:** Data range, if data beyond range will be not inputted.

**Variable limits:** when checked, low limit address and high limit address could be edit showed below;

**Show meter background:** This is for setting meter background. When not checked, the background color is transparent; When checked, there are four styles of pointer meter to select it according to needs.

**Show pointer:** When not checked, the pointer is not displayed; When checked, you could set the style and color of pointer.

**Show alarm area:** It provides alarm function in meter, you could set the 4 areas, and each area corresponds to a different alarm color.

**Show scale:** Display the scale on the object to observe the value. You need to set major scale, minor scale and scale value.


**Meter Type:** It sets the angel between the maximum and minimum value. It provides 7 kinds of styles, they are 180°, 210°, 240°, 270°, 300°, 330° and 360°.

**Start angle:** It sets the position where the minimum value is displayed.

**Position&size:** Set the position of the object in the screen and the size of the object. The object is displayed as square. If the width or the height of the object is changed, the other data will also be changed.

## Result

When configuration is completed, the object is shown as below picture when HMI is running.



🔍 **Note:** For the parameter setting, please refer to "text" in "Bit Switch".

## Bar

The bar graph shows the numerical change of the word address by means of bar graph.

## Description

Bar Chart

Graphic

1

Read address 40 Edit

Dual value display

Read address 41 Edit

Data format 16-bit unsigned

Digits setting 5.0 Edit

Variable Limits

Min value 0 Set

Max value 200

2

type 1

Bar direction 0°

Bar color

TextColor

Back color

3

Alarm setting

Count 4  Warning range using variable

Alarm value1	0	45	Color1	Yellow
Alarm value2	45	90	Color2	Cyan
Alarm value3	90	135	Color3	Orange
Alarm value4	135	200	Color4	Red

4

Show scale

Major scale 5

Minor scale 10

Major color

Minor color

Position

X 558 Y 26

Size

Width 172 Height 325

OK Cancel Help

### (1) Data setting

1. **Read address:** Read the value from the set PLC address.
2. **Dual Value Display:** Set two read addresses. The bar graph will show the value segment between the two read addresses.
3. **Data format:** It is for setting data format from read address.
4. **Digits setting:** It means the decimal point position. The decimal point position is effective only when data format is floating and decimal.

## (2) Display settings

1. **Type:** It is for setting bar display type, it provides two types.
  - Type1: Single scale display.
  - Type2: Double scales display.
2. **Bar direction:** horizontal display or vertical display.
3. **Back color:** User could freely set the color when check it.
4. **Text color:** Display color of the scale value.


## (3) Alarm settings

It provides alarm function in meter, users could set alarm range, users could set the 4 ranges. And each range corresponds to a different alarm color.

## (4) Show scale

It provides settings for scale on meter, users could select [Major scale] and [Minor scale], and set color for them.

## Result




When configuration is completed, the object shows as above picture, when HMI is running.

# Clock

This object displays HMI system time.

## Description



1. **Back type:** It is for clock dial style settings; it provides three types.
2. **Back color:** It is for setting color for clock dial, it is invalid when back type is 1.
3. **Hand type:** It is for clock hand style settings; it provides three types.
4. **Hand color:** It is for setting color for hand.
5. **Show second hand:** Check it to display second hand in clock.
6. **Second hand color:** It is for setting color for second hand.

## Result

As soon as configuration is completed, the object is shown as below picture, during HMI is running.




# Runbar

Run bar object could displays normal text and alarm text. User could select display content according to requirement.

When the alarm text is displayed, it could quickly and timely reflect the status of the current HMI alarm function for easy management and control.

When normal text is displayed, it provides two ways to set the display content to user (static text and dynamic text);

## Description



## (1) Basic settings

1. **Type:** It is for displaying content settings.
  - Move Text: Normal text.
  - Alarm: Alarm text.
2. **Transparence:** It sets the transparency of the object background.
3. **Reverse:** it sets text move right to left or left to right.
4. **Speed:** It sets text moving speed.
5. **Background:** It sets object background color.

6. **Text color:** It sets text color.
7. **Show Border:** Check it to show border for object.
8. **Border:** It sets object border color; it is visible only when [Show Border] is checked.

## (2) Display content settings

- If it shows static text, please set content in "text".
- If it shows dynamic text, please check [Read Address], and set address and length for it.
- If it shows alarm text, please select alarm information, such as time and date, alarm group number range.

## (3) Preview

It is for preview text content in object.

### Result


When configuration is completed, the object is shows as below picture, when HMI is running.

#### 1. Normal text



Test textTest textTest tex


#### 2. Alarm text



2019-07-05 16:14:48 too high|

🔗 **Note:** For the "Text" setting, please refer to "text" in "Bit Switch".

## Display




## Indirect window

Indirect window is used for displaying sub-screen in HMI project. You could control it to display different sub-screens by changing the value of read address.

### Description





### (1) Screen No.

There are two modes for sub-screen display, one is static screen, and the other is dynamic screen, and switch screen by change read address value. User could only choose one of the two modes.

1. **Indirect scree No.:** It is for setting read address to switch sub-screen.
2. **Screen No.:** Check it to enable static screen mode, and select screen for object.

### (2) Control display by address

Control display of the indirect object through bit address.

- Set ON: Display.
- Set OFF: Hide.

### (3) Position

It is for setting the position of sub-screen, the value is for coordinates of the top left point of it.

### (4) Size

It is for setting the size of sub-screen.

### Result

When configuration is completed as below, sub screen will be displayed as picture show.

1. Display static sub-screen.
2. Use HDX0.0 to control display or hide.




Indirect window  
display

## QR Code

### Introduction

It is similar to the universal QR code. You could scan this object to get the connection or content, but it provides content settings for QR code.

### Description



### (1) QR Set

1. **Variable QR:** It is for setting read address, the content of QR code is from this setting address.
2. **QR String:** It is for set static content for QR code.


#### **Note:**

- HMI machine ID address: HSW10494 ~ HSW10558.
- So if user want to use QR code to display machine ID in project screen, please check "Variable QR", and set address is HSW10494.
- When scanning the QR code by APP to monitor HMI, the default access password is 888888.

## Picture

Picture object is for displaying picture in HMI screen. After the picture is imported, the software will automatically convert the color depth of the picture to the picture matching the HMI.

### Description



## (1) Shape

1. **Shape:** Click shape to open the Shape Library for shape selection.
2. **Default shape:** Every object has its own default shape, click it will back to default.
3. **Discard:** Click it, object will display without shape.

## (2) Set Color

This is for set object color basic on shape, not all shape supports change color.

## (3) Picture display function

This is advanced function of picture object; user can change display picture when HMI is running. The supported formats are bmp, jpg, png, jpeg. This feature is unavailable for offline and online simulation.

1. **Root:** Set the save location of the picture, which can be set to U disk, SD card, but could not be set to Flash.

2. **Folder:** Set the name of the folder where the picture is located. The folder name can be up to 31 characters. (Note : The picture must be stored in the U disk folder and cannot be stored in the root directory of the U disk.)
3. **File address:** 16 consecutive addresses enter a picture name in the address (need to be the full name of the suffix), if the picture exists, the picture content is displayed; otherwise the default picture is displayed.

**Note:**

1. The image could be displayed in BMP, JPG, PNG, and JPEG formats. Images with a resolution of 1920 x 1080 or higher are not supported.
2. For the setting of [animations](#), see the "[Bit Switch](#)".

## Rotation picture

Rotation picture can rotate the image at a specified center or rotate it in a certain way. It is determined by the property settings.

Rotation Picture

**General**

**Position**  
 X  Y

Counter-Clockwise

**Appearance**

**Angle**  
 Min. angle  Max. angle

**Address**  
 Data Format    
 Rotation angle

**Rotation Centre**  
 Use rotation centre  
 X position  Y

Auto-rotation  
 Interval time  \*100ms Rotation Angle

Return

Enable Auto-Spin

Hide  
 Control Bit

Hide when OFF  Hide when ON

**Preview**

**Position:** Display the position of the rotation picture in the screen.

**Counter-Clockwise:** It sets the rotation direction of the picture. The default is to rotate clockwise. When checked, the rotation direction is counterclockwise.

**Appearance:** It sets picture for object, the picture is selected from Shape.

**Data format**

- **Data format:** It sets data format for [Address]->[Rotation angle].
  - BCD
  - 32-bit float
  - 16-bit signed decimal
  - 16-bit unsigned decimal
  - 32-bit signed decimal
  - 32-bit unsigned decimal
- **Min. angle:** It sets the starting angle of rotation (Valid in auto-rotation mode).
- **Max. angle:** It sets the ending angle of rotation (Valid in auto-rotation mode).

**Rotation angle:** the rotating angle is determined by designated address;

**Rotation center:** It shows the rotation center coordinates;

**Auto-rotation:** Taker the center of the image as the center of the picture when it is rotating.

**Cycle time:** Object will rotate every cycle time. Unit:100 ms.

**Rotation angle:** Object rotates designated angle everytime.

**Return:** Object will be reset to original position after maximum angle reached.

**Enable auto-spin:** When the address is set to ON, the picture will rotate automatically.


**Hide:** control the hiding status of the object through the status of the control bit address. The hiding mode can be divided into hide when OFF and hide when ON.

## Drop-down List

Drop-Down list is designed for display the designated state by text, to select the text in the list, the corresponding state will change, and the write address will change to the designated state value.

The drop-down list could write word address, and the value range is 0 to 31. The corresponding value can be displayed by text in the object. Click the drop-down box on the right of the object to list all the status text, and the drop-down box will be automatically withdrawn after setting.

### (1) General



### 1) Edit

1. **Read Address:** The data from designated address will be displayed.
2. **Same read-write address:** Configure "Write Address" is the same as "Read Address".
3. **Write Address:** Write data to designated address. The address can be different "Read Address".

### 2) Format

Set data format for object, it provides 16-bit unsigned decimal, 16-bit BCD, 16-bit unsigned decimal, 32-bit BCD, 32-bit unsigned decimal and 32-bit unsigned decimal.



### 3) State count

It could set the total number to display in the drop-list and supports up to 128 states (1 to 128). The default value of state is corresponding to the number of states. (State 1 corresponding to value 1). You can also click "state values" to set it according to your needs.

**State value:** You can set different values to correspond to different states, the setting window as below figure shows.







### 1) Centre

Check it to make the text centered;

## 2) Enable states text control

You can dynamically modify the text content in different states. When this feature is enabled, the text for each state set in the normal mode is invalid.

1. **Current state:** It is for setting state number for modification. For example, if the value is 3, it means that the text information in state 3 will be modified.
2. **Text address:** This address is used for the operation of the text component and is used to input the content displayed in the state. The length of the text is the number of text characters that can be entered, ranging from 1-127 characters.
3. **Trigger set text:** This address is used for saving modification.

## 3) Read state text from address

1. **Text start address:** the first address of occupied multiple consecutive addresses. Address length:  $[\text{Text length}/2] * [\text{state number} + 1]$ .
  - For example: 10 states, the address length=  $(10/2) * (10+1) = 55$ . It set HDW100 as start address, so the HDW100-HDW104 stores the currently selected text content, the HDW105-HDW109 displays the text in the first state, the HDW110-HDW114 displays the second, and so on.
2. **Refresh:** The drop-down list status value is updated according to the text address content. The drop-down list is not updated immediately, when the data in the text address change is completed, only the refresh is triggered, it will update.


# Camera display

Video display is advanced function in PI HMI, this object displays the camera screen in HMI, there are two modes, one is IP camera, and the other is USB camera. But IP camera requires settings in [Project settings], the detailed information, please refer to [[Camera](#)].

### Note:

This function requires special HMI model, the detailed information, please contact sales.

## IP Camera



### (1) Mode select

It is used for selecting modes; each mode uses different settings.

### (2) Use dynamic control instruction

Read a string from designated system address, and then combine the instruction to control the camera image.

When the dynamic control command is disabled, the complete camera control command need to be entered in order to display the camera contents.

### (3) Camera control instruction

This is for entering static instruction for camera, so that users can operation camera when HMI running;


### (4) Enable rtsp camera

This is another way to control camera, check it and set the function address.

### Camera Display usage method

(1) Usage 1: Suitable for users know camera account, password and device serial number.

Add the camera display object, select Net Camera, and enable rtsp camera and configured with a functional address, the followings use HDW0 as as example:



Register	Function	Length
HDW0	User name	20 words

<b>HDW20</b>	Password	20 words	
<b>HDW40</b>	Alias	20 words	
<b>HDW60</b>	Device Serial Number	43 words	
<b>HDW103</b>	Camera ID	1 word	
<b>HDW104</b>	Camera control	1 word	
	HDX104.0		Open Camera
	HDX104.1		Close Camera
	HDX104.2		Camera up
	HDX104.3		Camera down
	HDX104.4		Camera left
	HDX104.5		Camera right
	HDX104.6		Screenshots
	HDX104.7		Binding camera
	HDX104.8		Set alias
HDX104.9	Camera stops moving		
<b>HDW105</b>	<p>Camera Status</p> <p>=0 : Camera disconnected ;</p> <p>=1 : Camera connected properly ;</p> <p>=2 : Camera is being connected.</p>	1 word	

<b>HDW106</b>	<p>Screenshot save location :</p> <p>=0 : Screenshot save in Flash/IPCameraScreenShot ;</p> <p>=1 : Screenshot save in U Disk/IPCameraScreenShot ;</p> <p>=2 : Screenshot save in SDCard/IPCameraScreenShot.</p>	1 word
---------------	--	--------

- Fill in the camera ID with the camera serial number queried by "Camera Search Module", trigger the binding address, and fill in the camera information (user name, password, device serial number, etc.) of the ID into the corresponding function address.
- If the "Camera Search Module" is not enabled, you need to enter the camera information manually: user name, password, device serial number (S/N), which can be obtained from the label on the camera body.



- Trigger the "Open Camera" address to view the surveillance screen of the camera.

If the camera is successfully opened, you can set the alias of the camera, control the up/down/left/right movement of the camera (provided that the camera supports up/down/left/right control), and take screenshots.

If the camera is off, you can't set alias, camera rotation, screenshot, etc.

(2) Usage 2: Suitable for users know the camera account, password and camera IP

After enabling the rtsp camera and configuring the function address, additionally check Default configuration option, the configuration method and the function can address as follows.

Camera display ×

General

Net Camera  USB Camera

Use dynamic control instruction

Camera control instruction

Enable rtsp camera

function address

Default configuration  URL Configuration

Enable EZVIZ Cloud

Position

X	<input type="text" value="734"/>	Y	<input type="text" value="182"/>
---	----------------------------------	---	----------------------------------

Size

W	<input type="text" value="919"/>	H	<input type="text" value="524"/>
---	----------------------------------	---	----------------------------------



**Configuration** [X]

Default configuration

Username:

Password:

IP:

Port:

URL Configuration

OK Cancel

Register	Function		Length
<b>HDW0</b>	User name		20 words
<b>HDW20</b>	Password		20 words
<b>HDW40</b>	IP		8 words
<b>HDW48</b>	Port		1 word
<b>HDW49</b>	HDX49.0	Open Camera	1 word
	HDX49.1	Close Camera	
	HDX49.2		
	HDX49.3		

	HDX49.4		
	HDX49.5		
	HDX49.6	Screenshots	
	HDX49.7		
	HDX49.8		
	HDX49.9		
<b>HDW50</b>	Camera Status =0 : Camera disconnected ; =1 : Camera connected properly ; =2 : Camera is being connected.		1 word
<b>HDW51</b>	Screenshot save location : =0 : Screenshot save in Flash/IPCameraScreenShot ; =1 : Screenshot save in U Disk/IPCameraScreenShot ; =2 : Screenshot save in SDCard/IPCameraScreenShot.		1 word

- If you have set the default settings, directly trigger the function address to trigger the opening of the camera.
- The camera configured via ip only supports, turn on, turn off, screenshot basic functions.

(3) Usage 3: Suitable for users know the address of rtsp stream play.

After enabling the rtsp camera and configuring the function address, additional check URL configuration option, configuration method and function can address as follows.

Camera display

General

Net Camera  USB Camera

Use dynamic control instruction

Camera control instruction

Enable rtsp camera

function address

Default configuration  URL Configuration

Enable EZVIZ Cloud

Position

X  Y

Size

W  H

**Configuration** [X]

Default configuration

Username: admin

Password: wecon123

IP: 192.168.52.244

Port: 8000

URL Configuration

[OK] [Cancel]

Register	Function		Length
<b>HDW0</b>	User name		20 words
<b>HDW20</b>	Password		20 words
<b>HDW40</b>	IP		8 words
<b>HDW48</b>	Port		1 word
<b>HDW49</b>	HDX49.0	Open Camera	1 word
	HDX49.1	Close Camera	
	HDX49.2		
	HDX49.3		

	HDX49.4		
	HDX49.5		
	HDX49.6	Screenshots	
	HDX49.7		
	HDX49.8		
	HDX49.9		
<b>HDW50</b>	Camera Status =0 : Camera disconnected ; =1 : Camera connected properly ; =2 : Camera is being connected.		1 word
<b>HDW51</b>	Screenshot save location : =0 : Screenshot save in Flash/IPCameraScreenShot ; =1 : Screenshot save in U Disk/IPCameraScreenShot ; =2 : Screenshot save in SDCard/IPCameraScreenShot.		1 word

- If you have set the default settings, directly trigger the function address to trigger the opening of the camera.
- The camera configured via ip only supports, turn on, turn off, screenshot basic functions.

### **EZVIZ Cloud Description**

Camera display

General

Net Camera       USB Camera

Use dynamic control instruction

Camera control instruction

Enable rtsp camera

Enable EZVIZ Cloud

function address: HDW6000      Edit

Default configuration      Configuration

Position: X: 734      Y: 181

Size: W: 919      H: 524

确定      取消      帮助

Configuration

Required field

AppKey

Secret

Channel number

S/N

Optional field

IP

RTSP port

Verification code

OK Cancel

The function address will occupy the 125 word address, the following table is using the HDW6000 as a example:

Register	Description	Length	Data Format
<b>HDW6000</b>	AppKey of EZVIZ Cloud	20 Words	String
<b>HDW6020</b>	AppSecret of EZVIZ Cloud	20 Words	String
<b>HDW6040</b>	Device S/N of EZVIZ Cloud	43 Words	String
<b>HDW6083</b>	Channel number of EZVIZ Cloud	1 Word	16bit Unsigned
<b>HDW6084</b>	Device IP of EZVIZ Cloud	16 Words	String

<b>HDW6100</b>	RTSP Port of EZVIZ Cloud	1 Word	16bit Unsigned
<b>HDW6101</b>	Verification code of EZVIZ Cloud	20 Words	String
<b>HDX6121.1</b>	Confirmation of binding EZVIZ camera (=1, Confirm; =Others value, Unconfirm)	1 Bit	Bit
<b>HDW6122</b>	Device function control	1 Word	16bit Unsigned
<b>HDW6123</b>	Device status (=0, Close; =1, Open)	1 Word	16bit Unsigned
<b>HDW6124</b>	Result code of function control(HDW6122)	2 Words	32bit Signed

When the function control HDW6122 set to different value, it will trigger different function. After triggered, the HDW6122 will be reset to 0. The specific introduction like follows:

<b>Register Value</b>	<b>Function Description</b>
<b>1</b>	Open camera
<b>2</b>	Close camera
<b>3</b>	Move up
<b>4</b>	Move down
<b>5</b>	Move left
<b>6</b>	Move right



<b>7</b>	Move upper left
<b>8</b>	Move lower left
<b>9</b>	Move upper right
<b>10</b>	Move lower right
<b>11</b>	Zoom in
<b>12</b>	Zoom out
<b>13</b>	Short focal length
<b>14</b>	Long focal length
<b>15</b>	HD clarity
<b>16</b>	Smooth clarity
<b>17</b>	Stop control

The result code of function control will be displayed in HDW6124, the specific code as following table shows:

<b>Result Code</b>	<b>Description</b>	<b>Remark</b>
<b>-1</b>	Operation failed	Other reason(For example network error, device configuration error, etc.)
<b>-1001</b>	Internal error	Suggest to retry

<b>-1002</b>	Camera search: Request parameter is empty	Confirm the account and password whether correct or not
<b>-1003</b>	Camera search: Search failed	Confirm the device ethernet whether connect normal
<b>-1004</b>	Camera binding failed: Invalid camera ID	Confirm the camera ID whether is in the valid range
<b>-1005</b>	Camera opening failed: Cannot match the corresponding camera	Confirm the account, password and S/N whether correct or not
<b>-1006</b>	Camera opening failed: Cannot adapt minimum resolution	Confirm the camera supports ONVIF protocol or not
<b>-1007</b>	Camera opening failed: Cannot get the rtsp stream address	Confirm the camera supports ONVIF protocol or not
<b>-1008</b>	Camera opening failed: Cannot adapt the camera parameters	Confirm the camera supports ONVIF protocol or not
<b>-1009</b>	Camera opening failed: Open video stream failed	Confirm the camera whether is on running status, or whether open the camera too frequently
<b>-1010</b>	Camera closing failed: Camera on the closed status	Confirm the camera whether is on running status or not
<b>-1011</b>	Camera closing failed: Camera on the closed status	Confirm the camera whether is on running status or not

<b>-1012</b>	Screenshot failed: Camera not opened	Confirm the camera whether is on running status or not
<b>-1013</b>	Screenshot failed: Execution error occurred	Confirm the camera whether is on normal running status or not
<b>-1014</b>	Alias setting failed: Cannot match the corresponding camera	Confirm the S/N whether correct or camera whether is on running status
<b>-1015</b>	Pan-tilt controlling failed: Camera on the closed status	Confirm the camera whether is on normal running status or not
<b>-1016</b>	Pan-tilt controlling failed: Camera match failed	Confirm the account, password and S/N whether correct and the camera device whether supports pan-tilt movement
<b>1</b>	Operation success	Operation success
<b>201</b>	Play address created	Do not open the camera frequently
<b>401</b>	Unauthorized	Please contact the device administrator to enable operation permission
<b>403</b>	Operation prohibited	Please contact the device administrator to enable operation permission
<b>404</b>	Play address not obtain	Confirm the device network status
<b>403</b>	User does not exist	Confirm the AppKey and AppSecret whether correct

<b>10001</b>	Parameter error	Confirm the basic information of EZVIZ Cloud whether correct
<b>10002</b>	AccessToken abnormal or expire	Please try to reopen the camera
<b>10005</b>	AppKey abnormal	AppKey is frozen, please contact with EZVIZ customer service to unfreeze
<b>10017</b>	AppKey does not exist	Confirm the AppKey whether correct or not
<b>10030</b>	AppKey is unmatched with AppSecret	Confirm the AppKey and AppSecret whether correct
<b>20001</b>	Channel does not exist	Confirm the camera whether re-added or channel parameter whether changed
<b>20002</b>	Device does not exist	Confirm the S/N whether correct
<b>20006</b>	Network abnormal	Confirm the device network status, try again later
<b>20007</b>	Device offline	Confirm the device whether online or not
<b>20008</b>	Device response timeout	Operation too frequent, try again later
<b>20014</b>	S/N illegal	Confirm the S/N whether correct
<b>20018</b>	The current user does not own the device	Confirm the S/N whether correct
<b>20032</b>	Channel does not exist under the current user	Confirm the camera whether re-added or channel parameter whether changed

49999	Data abnormal	Please try to reopen the camera
60000	Device does not support pan-tilt controlling	Confirm the device whether supports pan-tilt controlling or not
60001	The current user does not have the permission of pan-tilt controlling	Please contact the device administrator to enable operation permission
60002	Device tilt reaches to the upper movement limit	Device control reach to limitation, do not repeat the operation
60003	Device tilt reaches to the lower movement limit	Device control reach to limitation, do not repeat the operation
60004	Device pan reaches to the left movement limit	Device control reach to limitation, do not repeat the operation
60005	Device pan reaches to the right movement limit	Device control reach to limitation, do not repeat the operation
60006	Current pan-tilt controlling operation failed	Pan-tilt operation failed, try again later
60019	Device stream is encrypted	Using the EZVIZ Cloud client software to close the stream encrypted, then remote monitoring will be able to use
60020	Unsupport this command	Confirm the device whether supports this operation or not

**Default Configuration** : Enable the default configuration, the initialization of the EZVIZ cloud camera display components will use the default configuration for binding, the screen can also be modified through the function address configuration information; do not enable the default configuration, the default initial configuration of the EZVIZ cloud camera display components are empty.

### **In the default configuration, the following are required :**

**AppKey** : EZVIZ cloud application information AppKey, up to 32 characters in length, only letters and numbers can be entered, which can be obtained through the EZVIZ cloud open platform.

**Secret** : EZVIZ cloud application information Secret, up to 32 characters in length, only letters and numbers can be entered, available through the EZVIZ cloud open platform.

**Channel number** : EZVIZ cloud device source channel number, 1~65535, no special modification, generally defaulted to 1, which can be obtained by viewing the EZVIZ cloud client software.

**S/N** : EZVIZ cloud device serial number, 0 to 80 characters in length, only letters, numbers and "-" can be entered, which can be obtained through the device information.

### **In the default configuration, the following are optional:**


**IP** : EZVIZ cloud device IP, which can be obtained by viewing the EZVIZ cloud client software.

**RTSP Port** : EZVIZ cloud device source rtsp port number, range 0~65535, no special modification, generally default to 554, can be obtained by viewing the EZVIZ cloud client software.

**Verification Code** : EZVIZ cloud device authentication code, up to 32 characters in length, obtainable through device information.

**Note:** The required content in the configuration only supports remote monitoring when the camera screen can be displayed, if there is a demand for the screen side can also display the camera screen, user need to fill in the optional content in the configuration.

## **USB Camera**



### 1) Mode select

It is used for selecting modes; each mode uses different settings;

### 2) Camera settings

**Function address:** It occupies a word for functional operation. Different value means different operations, as below table shows:

Value	Operation
1	Enable the screenshot function
2	refresh camera display object

**Camera state:** It shows the current camera states. It occupies a word address. Different value means different operations, as below table shows:

Value	Operation
1	Load the camera function successfully
2	Failed to load the camera function
3	Camera does not exist
4	Camera is not running
5	Initialize the camera successfully
6	Failed to initialize the camera
7	Screenshot successfully
8	Failed to screenshot
9	Connected camera
10	Removed camera
11	The cache is full
12	The cache is abnormal

### 3) Screenshot storage

The current screenshots are only allowed on the SD card. When the SD card does not exist the system will cache the latest 10 screenshots.



**Picture name:** The name of the image is controlled by the address. The length of the file name is limited to 64 words. If the image name address is not set, it will be named according to the time and displayed as [YYYYMMDDHHMMSS.bmp] and screenshot format is [.bmp].

#### 4) Global screenshot

If this function is enable, camera display object can perform the screenshot operation when HMI is running and save it as a .BMP image.

If this function is disabled, camera display object only performs the screenshot operation when it is displayed on screen.

#### 5) Resolution

The resolutions of different types of USB cameras are different, and the user can select the corresponding resolution according to the camera. When the user is unsure of the resolution of the camera, start with the smallest resolution until the image is clear.

#### 6) Use resolution size

Coordinate displays the object location in the screen, and size is the length and width of the object.

#### Note:


- When using USB camera, HD USB camera is not recommended, which is limited by the resolution displayed by HMI itself.
- When HMI is displayed horizontally, the USB camera screen displays normally. If select vertical display, USB camera can't display normally. (USB camera can only display normally when the display Angle of HMI is 0.)
- One HMI is only allowed to connect with one USB camera device. There is only one USB camera display part in the whole project screen, and the camera display part is not allowed to be placed on the public screen (1002: common Windows).
- Sometimes the USB camera may lose the image because of the influence in the field, then we suggest to PI9000 HMI and the recommended USB camera model.
- All below USB camera model have been tested by WECON to ensure the compatibility.
- Currently, only PI8000 and PI9000 series support the USB camera function. Recommended USB cameras include:
  - REB-USB 100W07M (supports 720p)
  - WX152HD (supports 720p)
  - RMONCAM G200 (supports 720p)
  - ASHU S300 (640\*480)

## Camera control

### Introduction

This is for control camera; this object need to be used with camera display object.

### Description



### 1) Use dynamic control instruction

Read a string from designated system address, and then combine the instruction to control the camera image.

When the dynamic control command is disabled, the complete camera control command be entered in order to display the camera contents.

### 2) Camera control instruction

This is for enter static instruction for camera, so that users can operation camera when HMI running;

### 3) Control bit

Trigger the switch to control the instruction.


### 4) Enable beep

The object will beep when operate.

# Flow component

The flow components are mainly used to reflect the flow state in process flow production. You could set the style of flow components according to requirements.

## Description



### (1) Color

1. **FlowFrn:** It sets outer border color of flow component.
2. **Block:** It sets the block color of flow component.
3. **FlowBg:** It sets background color of flow component.

### (2) Detail

1. **Pipe width:** It sets background width of flow component.
2. **Block width:** It sets block width of flow component.
3. **PipeFrn width:** It sets outer border width of flow component.

4. **Block length:** It sets block length of flow component.
5. **Transparence:** It sets transparence of flow component.(from opaque (0) to full transparence (100)). You could cooperate with transparence and other settings to meet display requirements.
6. **Ratio:** It sets display ratio of block and background (Display density of the block in flow component).
7. **Speed:** It setsflow speed of the block during HMI running.

### (3) Control

**It flows automatically by default, and the direction is from left to right, up to down.**

1. **Reverse:** It sets flow in reverse (default is left to right).
2. **Variable:** It sets bit address to control reverse flow or not.
  - **Set OFF:** Forward
  - **Set ON:** Reverse
3. **Address:** It sets bit address to control flow or not.
  - **Set OFF:** Stop
  - **Set ON:** Flowing

### (4) Preview

It is for preview object.



## Printer

The printing object is primarily suitable for print out or screenshots saving when connected to micro printer.


Printer has two types: **serial printer and USB printer**. Printf (printtext function) should be called when it's used to print fixed message in a script.

### Printer protocol

HMI provides printer protocol to users as below. If users want to connect printer to HMI, protocol is necessary.



## Description



### (1) Display settings

1. **Direction:** Four direction choices in printing: 0, 90, 180, and 270.
2. **Zoom in:** Check "Zoom in" to zoom printing content in proportion with paper size.

### (2) Trigger mode

1. **Trigger address:** When trigger address turns ON, printer starts to respond operation.
2. **Printer\ Save:** It sets operation for this object, printer object could support sending printing command to printer device, and including screenshot.

### (3) Save path

Valid when the save mode is selected, screenshot the content in printing object area and the save it in specified storage and folder, when trigger address turns ON.

Folder: It's available to select SD card or USB disk. Set the file name to "Abc" in folder, and it would automatically generate a folder "Abc" when you save picture first time, and all the pictures will save in this folder. The folder name consists of mixed uppercase and lowercase letters and numbers within 32 characters.

### Related issues

1. The printer supports the following models:
  - **Serial port printer:** WH-E22、 WH-A6, WH-A7, WH-A9, WH-E21, WH-AA, E222R90-0DE1182TGA, SP-RMD6A, SP-RMD6B, SP-RMD8A, SP-RMD8B, SP-RMD8C, SP-DVII, SP-RME4.

- **USB printer:** SP-EU80, SP-EU80N, SP-EU801SU-USB, SP-RME3UHB, SP-RME4, SP-RMD8CUH-USB.
2. How to use USB printer and USB disk at the same time?
- Plug the USB interface in the HMI into the Hub to expand the USB interface.


## Draw

It provides function of drawing graphics, setting text, displaying pictures, this part contains Text, Line, Polygon, Circle, Arc, Rectangle, Broken Line, Linear Scale, Arc scale, Table.



## Date

Date object displays local system date on the HMI screen.



### (1) Display

1. **Open:** It local to [Shape] to select object background picture.
2. **Default:** Click it to reset object background.
3. **No Shape:** It sets transparent background for this object.
4. **Font:** It local to [Font library] to select font for text in object.

### (2) Text color

It sets color for text in object.

### (3) Color

Valid when select SVG picture from [Shape], user can modify SVG color according to requirements.

### (4) Data format

It sets object display date or week, and format, detailed please refer to below table.




Classification	Properties	Display style
Format	Show date	YYYY/MM/DD: year/month/day MM/DD/YYYY: month/day/year DD/MM/YYYY: day/month/year
	Show week	Chinese 1 English 1 Chinese 2 English 2

🔗 **Note:** For [animations](#), see the "[Bit Switch](#)".

## Time

Date object displays local system time on the HMI screen



### (1) Display

1. **Open:** It local to [Shape] to select object background picture.
2. **Default:** Click it to reset object background.
3. **No Shape:** It sets transparent background for this object.
4. **Font:** It local to [Font library] to select font for text in object.

### (2) Text color

It sets color for text in object;


### (3) Color

Valid when select SVG picture from [Shape], user can modify SVG color according to requirements;

## Text

It adds text to HMI screen, and a object can be displayed in 8 languages (set in "All Languages") with a special address setting.

## Description




### (1) Current state

It used to switch the object states, but [Text] object only has one state, so this function is invalid.

### (2) All language

Because in PI HMI, all object can support text in 8 languages, so click it to open the 8 language edit window as below shows. And each language can set different font.



### (3) From Text Library

If user already setting text in "Text library", you could use text from "Text library" directly.

### (4) Windows

It displays three languages content and provides text display setting access.

### (5) Text color

It sets color for text in object.


### (6) Text background

It sets object background and it only supports color.

## Table

It is displayed in a table format in the HMI screen to meet the display needs of user.

### Description



## (1) General

1. **Rows:** It sets rows for table.
2. **Columns:** It sets columns for table.
3. **Table line width:** It sets table line width, the larger the value, the thicker the line.
4. **Frame line width:** It sets table frame line width, the larger the value, the thicker the line.
5. **Border:** It sets table line color, including table line and frame line.
6. **Transparence:** It sets the transparency of the object background.
7. **Fill style:** There are two options for it, one is display background, and the other is no background.
8. **Background:** Valid when select display background in "Fill style".


## (2) View

It is for preview object.

## Line

It is displayed in line format in the HMI screen to meet the display needs of user.

## Description



### (1) Display settings

1. **Line:** It sets line color.
2. **Line type:** It sets line type; it provides 9 types for user.
3. **Transparency:** It sets the transparency of the object background.

### (2) Line width control

In basic display settings, the line width can't be changed, but you could change width by address.

Read the numerical value of address to control the width of line. Display range of numerical value:1-10.

### (3) Coordinate control

Dynamically set the position coordinate between two points in line. Set four addresses respectively corresponding to the starting point and end point coordinate. If the numerical value of coordinate is over interface, the object will not be displayed.

#### (4) Color control

Dynamically set the color of the line. The values of the color RGB are controlled by three addresses, and the value range from 0 to 255.

#### (5) View


It is for preview object.

## Polygon

It is displayed in polygon format in the HMI screen to meet the display needs of user.


Right click to close polygon and then complete the creation procedure. Select the polygon, then click its point position to change its vertex coordinate after it is created.

#### Description



## (1) Display settings

1. **Border color:** It sets border line color.
2. **Border type:** It sets border line type.
3. **Border width:** It sets border line width.
4. **Transparence:** It sets the transparency of the object background.
5. **Coordinate editing:** It changes coordinate for all points in this object, as below shows.



Points	X	Y
1	88	185
2	242	157
3	293	259
4	237	336
5	135	317
6	48	280
7	65	241
8	80	188
9	91	183

6. **Filling pattern:** It can't be modified now.
7. **Background:** It sets background color of object.

## (2) Transparence control

Read the numerical value of address, control the transparency; value range: 0 to 100.

## (3) Color control

Dynamically set the color of background. The values of the color RGB are controlled by three addresses, and the value range from 0 to 255.

## (4) View


It is for preview object.

# Cycle/ Ellipse

It is displayed as cycle in HMI screen to meet the display needs of user.

## Description





## 1) Display settings

1. **Border:** It sets border line color.
2. **Frame width:** It sets border line type.
3. **Frame type:** It sets border line width
4. **Pattern:** It sets background type, there are four types.
5. **Background:** It sets background color of object, invalid when select [No fill] in [Pattern]
6. **Transparence:** It sets the transparency of the object background.

## 2) Transparence control

Read the numerical value of address, control the transparency; value range: 0 to 100.

## 3) Cycle

Check if for circle; uncheck it for ellipse.

#### 4) Color control

Dynamically set the color of background. The values of the color RGB are controlled by three addresses, and the value range from 0 to 255.

#### 5) Move Control

Dynamically set the position coordinate and size of circle/ellipse when HMI is running.

1. **X axis:** The length value moved along the X axis comes from the set address.
2. **Y axis:** The length value moved along the Y axis comes from the set address.
3. **Radius address:** The radius length of the circle/ellipse from the set address.

## Arc


The software uses arc drawing to specify the starting point and ending point, using a counterclockwise drawing method. The contour, start and end points of the arc can be modified on the screen. If the user wants to change the start and end points of the arc on the screen, the arc should be selected firstly.

### Description

#### (1) View

It is for preview object.

#### 2) Display settings



1. **Border:** It sets border line color.
2. **Line type:** It sets border line width.
3. **Line width:** It sets border line type.
4. **Fill style:** It sets background type, there are four types.
5. **Transparence:** It sets the transparency of the object background.
6. **Background:** It sets background color of object, invalid when select [No fill] in [Pattern].

### (3) Only show arc

Check it for displaying arc; Uncheck it for displaying sector;

### (4) Transparence control

Read the numerical value of address, control the transparency; value range:0-100.

### (5) Color control

Dynamically set the color of background. The values of the color RGB are controlled by three addresses, and the value range from 0 to 255.

## (6) Angle control

Dynamically set the shape of the arc, start angle and end angle are controlled separately by setting address.


## (7) Angle

It displays and sets the starting and ending angles of the arc.

# Broken line

The line segments are linked end-to-end to form a broken line, whose vertex coordinate can be modified by drafting, just like polygon.


## Description



## (1) Display settings

1. **Line color:** It sets line color.

2. **Line type:** It sets line type.
3. **Line width:** It sets line width.
4. **Transparence:** It sets the transparency of the object line.
5. **Coordinate editing:** It changes coordinate for all points in this object, as below shows.



Points	X	Y
1	88	185
2	242	157
3	293	259
4	237	336
5	135	317
6	48	280
7	65	241
8	80	188
9	91	183

### (2) Transparence control

Read the numerical value of address, control the transparency; value range:0-100.

### (3) Line width control

In basic display settings, the line width can't be changed, but user can change width by address.

Read the numerical value of address to control the width of line. Display range of numerical value:1-10.


### (4) View

It is for preview object;

## Linear scale

The linear scale is a linear scale that draws the specified area with a bisector. The specific scale of the scale can be marked with static text.

### Description



### (1) Display settings

1. **Line color:** It sets all line in object (including main and sub scale).
2. **Display direction:** It provides four modes for display.
3. **Main scale:**It sets the cell of the main scale.
4. **Sub scale:** It sets the cell of sub scale for every main scale.


### (2) View

It is for preview object;

## Arc scale

It displays the scale within the specified arc area. The arc scale needs to specify a center coordinate. The inner and outer circles have two concentric circles that specify the scale length and the display area. The scale is distributed counterclockwise between the start angle and the end angle.

### Description



**Line color:** It sets all line in object (including main and sub scale).

**Display direction:** It provides four modes for display.

**Main scale:** It sets the cell of the main scale.


**External radius:** It sets the distance from the center of the circle to the outer circle of object.

**Inner radius:** It sets the distance from the center of the circle to the inner circle of object.

**Start angle:** It displays and sets the start angles of the arc.

**End angle:** It displays and sets the end angles of the arc.

## Custom object



## Customized object

Customized object is provided for users to design the universal interface of object freely to meet customization requirements.

### Description

Customized Object

General

Function Address **1**

DLL file name **2**

Position X  Y  Size Width  Height

Custom address **3**

ID	Address
1	
2	
3	
4	
5	
6	
7	
8	
9	
10	

- Function Address:** the numerical value in this address is used as the function code of object to handle the corresponding operation.
- DLL file name:** Select needed dll file (i.e. dll files provided by users)
- Custom address:** users can add some function address to cooperate with dll file to complete other operations

### Note:

This is a custom-made object that requires the cooperation of WECON software engineers.

Required documents: two XXXXXX.dll files and an document.

- One dll file is used in PC and should be put under the dll\_pc folder in the software installation directory.
- One dll file is used in HMI and should be put under the dll\_hmi folder in the software installation directory.
- A document for illustrating the dll files.



